



KORO

VOCAL DOUBLER · HARMONIZER



MODEL KR-77

OWNER'S MANUAL

SUBVERSELAB

1. INTRODUCTION

KR-77

KORO makes one singer sound like a small group, and it will not sing a note the key cannot back up.

THREE STEPS — THAT IS THE WHOLE FLOW

- 1 Drop it on the vocal.** It opens on the TIGHT DOUBLE mood: a two-voice double, no harmony. Doubling needs no key.
- 2 Sing.** The key is read from the audio continuously while the singer sings. There is nothing to press and nothing to choose; the panel shows what it heard.
- 3 Pick a mood,** or raise HARMONY and turn COLOR to choose the interval.

KORO KR-77 is two effects in one unit. The **double** adds one to three gently re-performed voices that arrive at slightly different, slowly moving times: a human timing impression, not a chorus wobble. The **harmony** adds pitch-shifted voices above or below the lead, snapped to the key it hears, with the singer's vibrato and inflection kept. Both can run together.

The one rule that shapes everything else: **a harmony voice must never be a wrong note.** Fifths and octaves are consonant in every mode, so KORO plays them whenever a note is clearly sung. A third depends on the mode, so KORO plays one only on a note where every key it still considers likely agrees on it; otherwise that voice falls back to a plain unison double (or, with COLOR near the fifth, to the fifth). It is never replaced by an octave. Section 6 explains the rule, and what was measured.

LATENCY: FIXED 54 MS

KORO reports a fixed latency of **54.10 ms at 44.1 kHz** (2386 samples) to the host at all times, with HARMONY on or off. The doubler alone is delayed by the same amount so the host never sees the number change. Use your host's plug-in delay compensation. See Specifications for the figure at other sample rates.

2. INSTALLATION

MACOS & WINDOWS

SYSTEM REQUIREMENTS

- **macOS** (Apple Silicon and Intel, one universal build): VST3 and AU (Audio Unit).
- **Windows** (64-bit): VST3.
- Channel layouts: mono → mono, mono → stereo, stereo → stereo.
- Any host that loads VST3 or AU effects. KORO needs no internet connection and no activation once installed.

MACOS — STEPS

- Run the installer package (.pkg) you downloaded. It is signed with a Developer ID and notarised by Apple, so macOS opens it without any extra step.
- Choose what to install: the VST3 plug-in (/Library/Audio/Plug-Ins/VST3/KOR0.vst3), the Audio Unit (/Library/Audio/Plug-Ins/Components/KOR0.component) and the standalone app (/Applications/KOR0.app, the same panel outside a DAW). An older bundle named "SubverseLab Koro" is removed by the VST3 package.
- Restart your DAW, or force it to rescan its plug-in list.

WINDOWS — STEPS

- Copy the .vst3 folder to C:\Program Files\Common Files\VST3\.
- Rescan plug-ins in your DAW.
- If Windows blocks the downloaded files: right-click the zip, choose **Properties**, tick **Unblock**, then extract.

Getting the plugin: sign in at subverselab.com/launch and download; no activation needed.

3. PANEL TOUR

KR-77

The face reads left to right: name and model plate with the MOOD keys, then the display window, then the VU meter and the LOCK and REAR controls. Along the bottom, three groups of knobs: DOUBLE, HARMONY and OUT.



Front panel (the real KR-77 panel, MOOD CHOIR selected).

- 1 **Name block and MOOD keys** — KORO, "Vocal Doubler · Harmonizer", the **MODEL KR-77** plate, and six keys: TIGHT DOUBLE, ARABESK CHOIR, BACKING STACK, THIRD, FIFTH, CHOIR. A mood writes the knobs and the rear plate; you can move any of them afterwards.
- 2 **KEY display** — a red 7-segment digit shows the detected key note. Five scale lamps (MAJOR, MINOR, NIHAVENT, HICAZ, RAST) show the detected scale. They are a read-out, not a selector. Four confidence lamps show how sure the detector is. AUTO and LOCK lamps show whether the key is following the singer or held. The note "TO OVERRIDE: REAR KEY / SCALE" points to the rear plate.
- 3 **HARMONY lamp and LATENCY 54 MS** — lit while HARMONY is above 0. The latency is reported to the host at all times; the lamp lights only when HARMONY is above 0, because only then is it audible.

- 4 **COLOR annunciators** — LOW 3RD, HIGH 3RD, 5TH, OCT: the interval the COLOR knob currently points at. **SAFE UNISON** lights when a third was withheld on the note being sung (see section 6). The COLOR lamps follow the knob, not the decision made on each note.
- 5 **PITCH bar** — 48 lamps, 25 cents per lamp, covering one octave from the detected key. **IN** marks the sung note; **OUT** marks the first harmony voice. Both are driven by the tracker, not drawn for effect.
- 6 **VU meter** — output level, left and right.
- 7 **LOCK** toggle — holds the detected key. **REAR** key — turns the unit around to the set-up panel.
- 8 **DOUBLE group** — DOUBLE, WIDTH, TONE.
- 9 **HARMONY group** — HARMONY, COLOR.
- 10 **OUT group** — OUTPUT, BYPASS, and the LATENCY 54 MS lamp.



Rear plate (set-up panel). The front MOOD writes these; change them only to override it.

4. CONTROLS

FULL REFERENCE

FRONT PANEL

CONTROL	RANGE / DEFAULT	WHAT IT DOES
MOOD	6 keys · TIGHT DOUBLE	Recalls a complete set of settings (section 5). Also supplies what has no knob: the doubler's timing character and the number of harmony voices.
DOUBLE	0–10, 0 = OFF · 5.6	Amount of doubling, and how many voices. 0–3.0 gives 1 voice, above 3.0 to 6.5 gives 2, above 6.5 gives 3. The dry/wet balance of the double rises to 0.75 at 10. The voices start 8, 21 and 34 ms behind the lead; the mood shortens that (TIGHT DOUBLE brings it to about 3, 8 and 12 ms) and sets a slow drift of up to ± 12 ms (0.55, 0.93 and 1.31 Hz, one rate per voice).
WIDTH	0–10 · 3.8	Stereo spread. On the double: voice 1 goes left, voice 2 right, voice 3 sits centre-back. It also scales the harmony voices' pan positions.
TONE	DARK–BRIGHT, 3–16 kHz · 11.1 kHz	High-cut on the doubled voices and on the harmony sum. The display value follows the cut-off in Hz.

HARMONY	0–10, 0 = OFF · OFF	Amount of harmony. Dry gain is $\min(1, 2(1-h))$ and harmony gain is $\min(1, 2h)$, with $h = \text{knob} \div 10$: at 5 the lead and the harmony are both at full level, at 10 you hear the harmony voices alone. The harmony is built from the dry input, so it works alongside DOUBLE.
COLOR	LOW 3RD · HIGH 3RD · 5TH · OCT · set by mood	One knob for the interval. With one harmony voice the detents are a low third (–2 scale steps), a high third (+2), a fifth (+4) and an octave (+7), and the positions between them crossfade two neighbouring intervals at equal power. With two or three voices, each voice glides from the set –2 / +2 / +4 (COLOR at LOW 3RD) to +2 / +4 / +7 (at OCT). The detected key decides the exact notes; in Chromatic the steps are semitones.
OUTPUT	–12 to +12 dB · 0 dB	Final gain, applied after the double and harmony.
LOCK	On/off · off	Freezes the detected key and its confidence while the singer keeps going. Has no effect while a KEY or SCALE override is set on the rear plate.
BYPASS	On/off · off	Crossfades (20 ms) to the dry signal. The dry path is delayed by the same 54 ms, so bypassing never moves the vocal in time.
REAR	Key	Shows the rear plate. Changes nothing by itself.

REAR PLATE

CONTROL	RANGE / DEFAULT	WHAT IT DOES
LEVEL 1 · 2 · 3	0–10 · set by mood	Level of each harmony voice relative to the dry lead (linear: 10 = equal to the dry). The voice's level is matched to the singer by a 40 ms envelope follower, so LEVEL stays relative as the singer moves. LEVEL 2 and LEVEL 3 act only in CHOIR, the only mood with three harmony voices; in the other five moods there is one harmony voice and they do nothing.
PAN 1 · 2 · 3	L 100 – C – R 100 · set by mood	Position of each harmony voice (balance law; centre is unity on both sides). WIDTH multiplies these. PAN 2 and PAN 3 act only in CHOIR (see LEVEL).
GLIDE	0–120 ms · 40 ms	Portamento of the interval between notes. 0 snaps; higher values slide the harmony voice from one target to the next.
TIMING	0–30 ms · 6 ms	Late entry of the harmony voices behind the lead (voice 1 $\times 1.0$, voice 2 $\times 0.55$, voice 3 $\times 0.8$).
KEY	AUTO, C, C#, D ... B · AUTO	AUTO follows the detector. Any note fixes the root.
SCALE / MAKAM	AUTO, MAJOR, MINOR, NIHAVENT, HICAZ, RAST, CHROM · AUTO	AUTO follows the detector. Any other setting fixes the scale. If either KEY or SCALE is set, KORO switches to a manual key: whatever is left on AUTO still follows the detector, and every interval is a plain scale degree with no safety gate (you have told it the key).
MONO SAFE	On/off · off	Puts the doubled voices on the sides only (left plus, right minus) and leaves the middle as your lead, so a mono sum is exactly the input: no comb filtering when the mix is summed to mono (measured: mono response ripple 0.05 dB, against 4.4 dB with MONO SAFE off at DOUBLE 10 / WIDTH 10). WIDTH sets how much of the doubles goes to the sides. Harmony voices are not affected.

UNDO AND REDO

- **macOS:** Cmd+Z undoes, Cmd+Shift+Z redoes. **Windows:** Ctrl+Z undoes; Ctrl+Shift+Z or Ctrl+Y redoes.
- One knob move is one step, from the moment you press the mouse button to the moment you let go. Several controls moved together (an X/Y drag, a mood key, a preset) are one step too.
- Click the plug-in window first so it has the keyboard. If your DAW takes the key before the plug-in does, use the DAW's own undo.
- Moves made by host automation are not in the plug-in's history: the DAW's own undo takes those back. Loading a project, a preset file or a saved state starts a new history. The last 200 steps or more are kept.
- A mood key is one step, including everything the mood writes to the rear plate.

5. MOODS

SIX STARTING POINTS

A mood is a stored set of settings, recalled when you press its key. Key detection is always automatic in every mood. Pressing a mood overwrites the front knobs and the rear plate with its values; after that, everything is yours to move. The first three are doubler-only; the last three add harmony.

MOOD	DOUBLE	HARMONY	CHARACTER
TIGHT DOUBLE	DOUBLE 5.6 (2 voices) · WIDTH 3.8 · TONE 11.1 kHz	Off	Two close, tight voices. Thickens a lead without announcing itself.
ARABESK CHOIR	DOUBLE 7.3 (3 voices) · WIDTH 9.2 · TONE 7.9 kHz	Off	Three loose, wide voices with a lot of timing drift.
BACKING STACK	DOUBLE 8.3 (3 voices) · WIDTH 7.0 · TONE 6.1 kHz	Off	A darker three-voice stack for backing vocals.
THIRD	Off · WIDTH 10 · TONE 12.4 kHz	HARMONY 5 · COLOR HIGH 3RD · 1 voice at level 6.3, pan R 35	One voice a third above. Falls back to a plain unison double (3 dB quieter) when the key is not certain on that note.
FIFTH	Off · WIDTH 10 · TONE 12.4 kHz	HARMONY 5 · COLOR 5TH · 1 voice at level 6.3, pan L 35	One voice a perfect fifth above. Needs no key knowledge at all.
CHOIR	DOUBLE 4.0 (2 voices) · WIDTH 10 · TONE 9.7 kHz	HARMONY 5 · COLOR LOW 3RD · 3 voices, levels 5.6 / 5.6 / 4.5, pans L 60 / R 60 / R 25, TIMING 12 ms	Three harmony voices (-2, +2, +4) plus a light double of the lead.

Every mood loads GLIDE 40 ms, TIMING 6 ms (CHOIR: 12 ms) and MONO SAFE off, with the key on AUTO.

KEY DETECTION: ALWAYS ON

A pitch tracker (YIN, 5 ms steps, 70–1000 Hz, mono sum of the input) follows the singer. KORO collects steady voiced notes into a pitch-class histogram with an 8-second memory, removes the singer's own tuning offset, and scores 48 candidates: 12 roots × MAJOR, MINOR, HICAZ, RAST. NIHAVENT and CHROM are never chosen automatically; they exist as manual overrides. A first key appears after at least one second of steady singing with a clear leader. To change an established key, a challenger must lead continuously for 1.5 seconds, so a passing note does not flip it.

THE SAFE RULE: PER NOTE

- **One decision per note.** A new note starts after 60 ms without voice, or when the pitch moves more than 80 cents away from the held note. The interval for that note is decided 70 ms after the onset and held until the next note, so the harmony never changes interval inside a held note. Before the first decision the voice stays at unison. Breaths and consonants pass through unshifted.
- **Fifth and octave.** Once a note is clearly sung, a perfect fifth (± 702 cents) and an octave (± 1200 cents) are always allowed, whatever the key.
- **Thirds.** KORO keeps every key whose score is within 0.08 of the best (between 1 and 6 keys). It plays a third only if all of them give the same third for the note being sung. If they disagree, the third is withheld and the SAFE UNISON lamp lights. The voice then plays a plain unison double, 3 dB quieter, when COLOR is at or below the midpoint between HIGH 3RD and 5TH, and the perfect fifth when COLOR is above that midpoint (up to just before OCT). A withheld third is never replaced by an octave; the octave sounds only where COLOR points at it.
- **No hard switches.** Each harmony voice fades between intervals over 250 ms at constant power, so COLOR moves and key changes never click.

The confidence lamps show how sure the detector is, but the safe rule above is what protects the note, not a threshold on that number.

WHAT WAS MEASURED

- Synthetic vocals with known keys: C Major found at 3.01 s, D Hicaz at 2.06 s, A Minor at 1.54 s after the start.
- Noise: no key is claimed and the harmony voice stays at unison. Input with no voice in it passes through at gain 1.0000, with a residual of -240 dB.
- A real female pop vocal, 20 s (2651 voiced frames): a third was played on 31.5 % of them and unison on the rest; the SAFE lamp was lit on 65.2 % of the voiced frames. No third was ever played without every plausible key agreeing on it at that moment (0 exceptions), and 5 of 834 third frames (0.6 %) disagreed with the key KORO finally settled on (F Major).
- The honest limit: a Major key and its relative Minor share every note. When the singer never sings the note that tells them apart (B versus B-flat in F Major or D Minor, for example), KORO cannot know which key it is in, and it withholds thirds on the notes where the answer would differ. It would rather sing a plain unison than a wrong third.

LEAD THICKENER

Mood: TIGHT DOUBLE · DOUBLE 5.6 · HARMONY off

The opening state. Two close voices behind the lead, with slow drift. Turn DOUBLE below 3.0 for a single voice.

A QUIET THIRD

Mood: THIRD · HARMONY 3.5

At 3.5 the lead stays at full level and the harmony sits at 0.7 of its level. Where the key is unsure on a note, that voice plays a plain unison double instead, and the SAFE UNISON lamp shows it.

BACKING CHOIR

Mood: CHOIR · COLOR LOW 3RD → OCT (move slowly) · WIDTH 10

Three harmony voices and a light double. Sweeping COLOR moves each voice from the set -2 / +2 / +4 to +2 / +4 / +7 without a click.

WHEN YOU ALREADY KNOW THE KEY

REAR: KEY = D · SCALE = HICAZ · then any harmony mood

A manual key is trusted: every interval becomes a scale degree of D Hicaz, with no safe-rule gate. Leave SCALE on AUTO to fix only the root, or KEY on AUTO to fix only the scale.

STABLE HARMONY OVER A LONG TAKE

Sing a verse, then press LOCK

LOCK holds the key the detector reached, so a long note or a modal turn cannot move it. Release it to follow the singer again.

8. SPECIFICATIONS

MEASURED

ITEM	VALUE
Formats / Platform	macOS (Apple Silicon and Intel): VST3, AU · Windows (64-bit): VST3
Channel layouts	Mono → mono, mono → stereo, stereo → stereo
Latency (fixed, HARMONY on or off)	2386 samples at 44.1 kHz (54.10 ms) · 2596 at 48 kHz (54.08 ms) · 5179 at 96 kHz (53.95 ms)
Pitch tracker	YIN, 5 ms hop, 70–1000 Hz; tracks one voice at a time. Vibrato tracking error: mean 0.94 cents, 95th percentile 2.02 cents
Harmony accuracy	Sine test, +2 (third): 277.18 Hz against a 277.18 Hz target; +4 (fifth): 329.62 Hz against 329.63 Hz. On a real vocal 99.5 % of voiced frames follow the target within 30 cents
Double pitch drift	–7.9 cents at worst in the self-test (limit ± 15 cents)
CPU (engine self-test)	60 s of audio with double and harmony in about 2 s on the development machine
Undo / Redo	Cmd+Z / Cmd+Shift+Z (macOS); Ctrl+Z / Ctrl+Shift+Z or Ctrl+Y (Windows)
Code signing	macOS installer signed with a Developer ID and notarised by Apple
Getting the plugin	Sign in at subverselab.com/launch and download — no activation needed

MEASURED BEHAVIOUR (SELF-TEST: 51 ENGINE CHECKS AND 55 PLUG-IN CHECKS, ALL PASS)

- Determinism: identical output, bit for bit, across runs.
- Double and harmony are independent: the difference between "both" and "double only" equals the harmony part to within $6e-8$.
- Latency: reported equals measured (impulse and voiced cross-correlation) at 44.1, 48 and 96 kHz.
- No clicks or discontinuities during COLOR sweeps, manual key changes, or an automatic key change mid-phrase (largest step $1.82\times$ the largest step of the dry vocal).
- Unvoiced passthrough: gain 1.0000, residual -240 dB.

NOT DONE YET

- Monophonic material only: the tracker follows one voice. A group recording or a chord will not be harmonised correctly.
- Latency is 54 ms by design, not zero. Use plug-in delay compensation.